Cellecta ScreedBoard 28 laid on timber sub-floor Solid timber joists Use with timber frame walls only

Floating floor Cellecta ScreedBoard 28 (See Table TF10 for full details)

Floor decking 15mm thick (min) OSB

Joists 220mm (min) solid timber joists

Absorbing 100mm (min) quilt insulation material (10-36g/m³) between joists

Ceiling See *Table TF10* for ceiling treatment






Table TF10

Fig. TF10

HOMEBUILDING



^{*} Code for Sustainable Homes (CSH) credits quoted are typical. Mat 1 value taken from the BRE Green Guide. Pol 1 credit is only awarded if all the other insulation products used have a GWP of <5. Hea 2 credits are based on the floor being pre-completetion tested and the separating wall performing to at least the same acoustic standard. Credits subject to relevant category weighted value. See page 5 for further information.


Acoustic value

Values quoted are typical, based on the treatment being installed correctly and pre-completion

Airborne performance tested in accordance with BS EN ISO 140-4:1998 Impact performance tested in accordance with BS EN ISO 140-7: 1998

Design & installation details - Cellecta ScreedBoard® 28


The acoustic performance of the floor structure will be compromised if the ScreedBoard 28 is not completely isolated from the timber sub-floor, soil pipes, door frames, surrounding walls and their treatments. To address this risk, each potential problem area needs to be detailed accordingly.



Fixing tools




1 Door threshold




Leave a 5-10mm expansion gap between the habitable area and the communal area ScreedBoards.

Baths, shower trays and sanitary ware built off floor treatment.




Baths, shower trays and sanitary ware can be built directly off the ScreedBoard 28. Under no circumstance should screws penetrate the resilient layer.




Wall treatments <u>MUST</u> be isolated from the ScreedBoard 28 with YELOfon FS50 strip.

2 Metal frame partition built off the floor treatment




3 Timber stud partition built off the floor treatment




Non-load bearing metal frame or timber stud walls can be built directly off the ScreedBoard 28. Care should be taken to ensure screws <u>DO NOT</u> penetrate the resilient layer.

5 Baths, shower trays and sanitary ware built off the structural floor




Baths. shower trays and sanitary ware built off the structural floor should be isolated from the ScreedBoard 28 and any floor finished.




Wall treatments <u>MUST</u> be isolated from the ScreedBoard 28 with YELOfon FS50 strip.

6 Metal frame partition built off the



Lightweight partition walls built off the structural floor <u>MUST</u> be isolated from the ScreedBoard with YELOfon FS50 strip.

Timber stud partition built off the
structural floor



Lightweight Internal walls built off the structural floor <u>MUST</u> be isolated from the **ScreedBoard** with YELOfon FS strip.